

MOBEYE SIM CARD


How to place a SIM card in the unit

A SIM card can be of any provider, preferably an M2M SIM (machine-to-machine SM). The size needs to be “normal”; if your SIM card has a smaller size, you can apply a SIM adapter. Check if your device needs a 2G SIM card. Mobeye offers Mobeye SIMs that will work in your country.


- Unlock the lid of the SIM card holder by shifting it to the outside.



- Open the lid.
- Shift the SIM card into the holder as indicated in the picture.



- Close the lid.



- Gently press the lid down and shift it to the inside to lock it.

